



## **I.O. Shen Knife Care**

**Please follow these instructions for the safe use and long life of your I.O. Shen knives:**

- Always store knives out of reach of children.
- Never store knives loose in a drawer.
- Never leave sharp knives submerged in washing up water.
- The cutting edge of I.O. Shen knives is extremely hard and is therefore liable to chip if used to chop bone, frozen food or other hard objects.
- Washing I.O. Shen knives in a dishwasher is not recommended. It is advisable to wash them by hand, dry them immediately and then store them safely.